11-90-013

Veloped Rain Cover (S) – User Guide

Scan the QR-code with your smart phone or device to view video instructions.

Rain cover that protects the seat and basket of the Veloped.

Veloped 2-color design: silver/black



1 Fasten the string.

Fasten the elastic string around the upper frame tube.
Note: Turn the cover so you get the desired colour on the cover.



2 Second attachment point.

The rain cover can also be fastened at the rear end.

">



3 Front attachment point.

The rain cover is wrapped around the front of the frame.



4 When walking.

Loosen the rear elastic strings when you're walking.



5 Store rain cover.

Store the rain cover the basket or in the zippered pocket.



6 Ready for use in rainy weather.